

KENWOOD

KDV-S221P

DVD PLAYER

INSTRUCTION MANUAL

LECTEUR DE DVD

MODE D'EMPLOI

DVD-Player

BEDIENUNGSANLEITUNG

DVD-SPELER

GEBRUIKSAANWIJZING

LETTORE DVD

ISTRUZIONI PER L'USO

REPRODUCUTOR-DVD

MANUAL DE INSTRUCCIONES

LEITOR DE DVD

MANUAL DE INSTRUÇÕES

Kenwood Corporation



Contents

Safety precautions	3	Accessories	19
Notes	4	Installation	19
Common features	8	Connecting Wires to Terminals	20
Power		Troubleshooting Guide	21
Play		Specifications	22
Mute			
Skip			
Fast Forward and Reverse			
Repeat Play			
A-B Repeat Play			
Random Play			
Program Play			
Switching Display			
DVD Video/Video CD/Video file/Picture file features	12		
Search Play			
DVD menu/Top (title) menu			
Audio Language select			
Subtitle Language select			
Picture Angle select			
Zoom			
PBC			
Slow Motion play			
Frame-by-frame playback			
Slide show			
Picture Rotation			
CD/Audio file features	15		
Direct Skip Play			
Play Time Search			
Search Play			
Setup menu	16		
Setup menu			
DISC menu			
VIDEO menu			
AUDIO menu			
DISPLAY			
OTHER			

Safety precautions

⚠ WARNING

To prevent injury or fire, take the following precautions:

- To prevent a short circuit, never put or leave any metallic objects (such as coins or metal tools) inside the unit.
- Do not watch or fix your eyes on the unit's display when you are driving for any extended period.
- Mounting and wiring this product requires skills and experience. For safety's sake, leave the mounting and wiring work to professionals.
- Do not connect the unit to the front monitor. This unit is for rear seat entertainment.
- Do not use any power cable other than the accessory. This could cause fire.

⚠ CAUTION

To prevent damage to the machine, take the following precautions:

- Make sure to ground the unit to a negative 12V DC power supply.
- Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity. Also avoid places with too much dust or the possibility of water splashing.
- When replacing a fuse, only use a new fuse with the prescribed rating. Using a fuse with the wrong rating may cause your unit to malfunction.
- Use only the screws provided or specified for installation. If you use wrong screws, you could damage the unit.

NOTE

- If you experience problems during installation, consult your Kenwood dealer.
- The illustrations of the display and the panel appearing in this manual are examples used to explain more clearly how the controls are used. Therefore, what appears on the display in the illustrations may differ from what appears on the display on the actual equipment, and some of the illustrations on the display may be inapplicable.

Lens Fogging

Right after you turn on the car heater in cold weather, dew or condensation may form on the lens in the CD player of the unit. Called lens fogging, CDs may be impossible to play. In such a situation, remove the disc and wait for the condensation to evaporate. If the unit still does not operate normally after a while, consult your Kenwood dealer.

Cleaning the Unit


If the faceplate of this unit is stained, wipe it with a dry soft cloth such as a silicon cloth.

If the faceplate is stained badly, wipe the stain off with a cloth moistened with neutral cleaner, then wipe neutral detergent off.








- Applying spray cleaner directly to the unit may affect its mechanical parts. Wiping the faceplate with a hard cloth or using a volatile liquid such as thinner or alcohol may scratch the surface or erase characters.


Region codes in the world



DVD disc marks

Symbol	Description
	Indicates a region number. The discs with this mark can be played with any DVD player.
	Indicates the number of audio languages recorded. Up to 8 languages can be recorded in a movie. You can select a favorite language.
	Indicates the number of subtitled languages recorded. Up to 32 languages can be recorded.
	If a DVD disc has scenes shot from multiple angles, you can select a favorite angle.
	Indicates the type of screen for the image. The left mark indicates that a wide image picture (16:9) is displayed on a standard TV set screen (4:3) with a black band at both the top and bottom of the screen (letter box).

Restrictions due to difference between discs

 Some DVD and VCD discs can be played only in certain playback modes according to the intentions of the software producers. As this player plays discs according to their intentions, some functions may not work as intended by you. Please be sure to read the instructions provided with each disc. When an inhibition icon is displayed on the monitor, it indicates that the disc being played is under the restriction as described above.

Use of "DualDisc"

When playing a "DualDisc" on this unit, the surface of the disc that is not played may be scratched while the disc is inserted or ejected. Since the music CD surface does not conform to the CD standard, playback may be impossible.
(A "DualDisc" is a disc with one surface containing DVD standard signals and the other surface containing music CD signals.)

About the usable temperatures

The protective circuit in the unit activates when the temperature inside the DVD player exceeds 60°C (140°F). Refer to <Troubleshooting Guide> (page 21).

List of playable discs

Disc types	Standard	Support	Remark
DVD	DVD Video	○	
	DVD Audio	×	
	DVD-R	○	MP3/WMA/AAC/JPEG/DivX Playback
	DVD-RW	○	Multi-border/Multisession (Playback depends on authoring conditions)
	DVD+R	○	
	DVD+RW	○	
	DVD-R DL (Dual layer)	○	Only video format
	DVD+R DL (Double layer)	○	
CD	DVD-RAM	×	
	Music CD	○	CD-TEXT/8-cm (3 inch) discs supported.
	CD-ROM	○	MP3/WMA/AAC/JPEG/DivX playback
	CD-R	○	DivX playback
	CD-RW	○	Multisession supported
			Packet write not supported.
	DTS-CD	○	
	Video CD (VCD)	○	
	Super video CD	×	
	Picture CD	○	
	CD-EXTRA	△	Only music CD session can be played.
	HDCD	△	Sound quality of normal CD music
Others	CCCD	×	
	Dualdisc	×	
	Super audio CD	△	Only CD layer can be played.

○ : Playback is possible.

△ : Playback is partly possible.

× : Playback is impossible.



- When buying DRM enabled contents, check the Registration Code in the <REGISTRATION> (page 18). Registration Code changes each time a file with the displayed Registration Code is played to protect against copying.

About the functions by playback source

In this manual, functions that can be used with various playback sources are indicated as follows:

[DVD]: Function of during DVD playback only.

[VCD]: Function of during Video CD playback only.

[CD]: Function of during CD playback only.

[AUDIO]: Function of during Audio file playback only.

[DivX]: Function of during Video file playback only.


[PIC]: Function of during JPEG/Picture CD playback only.




Handling discs

- Do not touch the recording surface of the disc.
- Do not stick tape etc. on the disc, or use a disc with tape stuck on it.
- Do not use disc type accessories.
- Clean from the center of the disc and move outward.
- When removing discs from this unit, pull them out horizontally.
- If the disc center hole or outside rim has burrs, use the disc only after removing the burrs with a ballpoint pen etc.

Discs that cannot be used

- Discs that are not round cannot be used.



- Discs with coloring on the recording surface or discs that are dirty cannot be used.
- This unit can only play the CDs with   . This unit may not correctly play discs which do not have the mark.
- You cannot play a CD-R or CD-RW that has not been finalized. (For the finalization process refer to your CD-R/CD-RW writing software, and your CD-R/CD-RW recorder instruction manual.)

About Audio files

• Playable Audio file

MP3 (.mp3), WMA (.wma), AAC (.m4a)



- If music of normal CD and other playback systems are recorded in the same disc, only the playback system recorded at the first setout is played.

• Playable MP3 file

MPEG 1/2 Audio Layer 3 file
Transfer bit rate: 8 – 320 kbps/ VBR
Sampling frequency: 8 – 48 kHz

• Playable WMA file

The file in accordance with Windows Media Audio (Except for the file for Windows Media Player 9 or after which applies the new functions)

Transfer bit rate: 5 – 320 kbps/ VBR
Sampling frequency: 8 – 48 kHz

• Playable AAC file

Transfer bit rate: 8 – 384 kbps/ VBR
Sampling frequency: 8 – 48 kHz

• Playable disc media

CD-R/RW/ROM, DVD-ROM/±R/RW

• Playable disc file format

ISO 9660 Level 1/2, Joliet, Romeo

• The maximum number of characters for display

12 characters

• Limitation of structure for the file and the folder

Maximum number of directory levels: 8

Maximum number of folders: 255

Maximum number of files per folder: 999

Maximum number of files per disc: 1254

Although the audio files are complied with the standards listed above, the play maybe impossible depending on the types or conditions of media or device.



- Attach the correct extension for the Audio file (MP3: ".MP3", WMA: ".WMA", AAC: ".m4a")
- Do not attach the extensions to files other than the Audio file. If the extension is attached, the file, which is not the Audio file, will play and outputs a loud noise, causing damage to the speaker.
- The files with copy protection cannot be played.
- The unit may not be compatible with upgrade of compression format standard and additional specifications.
- CD-RW discs which are quick formatted by the writing software cannot be used.
- When recording to the maximum CD-R/RW media capacity at once, the writing software is set to "Disc at once".
- File/Folder name is the number of the characters including the extensions.

About Picture files

Acceptable picture files

- Format: JPEG

- Baseline format:

Up to a maximum of 8192(W) × 7680(H) pixels

- Progressive format:

Up to a maximum of 1600(W) × 1200(H) pixels



- Enlarges and reduces images up to the size shown above to fit to the screen.
- The picture files with information attached (such as Exif) may not be displayed or operated (e.g.: rotation display) properly.

Extension

Picture file must have the following extension:

.jpg

Acceptable discs, disc formats, file and folder names and playing order are the same as those for audio files. Refer to <About Audio files>.

About Video files

Acceptable video files

- Format: DivX

- Version: 3, 4, 5

- Sound Format: MP3, AC3

- Transfer bit rate: 8 – 320 kbps/ VBR

- Size of picture

PAL: 720(W) × 576(H) pixels

NTSC: 720(W) × 480(H) pixels



- Enlarges and reduces images up to the size shown above to fit to the screen.
- The picture files with information attached (such as Exif) may not be displayed or operated (e.g.: rotation display) properly.

Extensions

Picture files must have one of the following extensions:

.avi, .divx

Acceptable discs, disc formats, file and folder names and playing order are the same as those for audio files. Refer to <About Audio files>.

About DivX

DivX is a popular media technology created by DivX, Inc. DivX media Files contain highly compressed video with high visual quality that maintains a relatively small file size. DivX files can also include advanced media features like menus, subtitles, and alternate audio tracks. Many DivX media files are available for download online, and you can create your own using your personal content and easy-to-use tools from DivX.com.


About DivX Certified

DivX Certified products are officially tested by the creators of DivX and guaranteed to play all versions of DivX video, including DivX 6. Certified products qualify for one of several DivX Profiles that designate the type of video the product supports, from compact portable video to high-definition video.

Loading the battery

Use one lithium battery (CR2025).

Insert the battery with the + and – poles aligned properly, following the illustration inside the case.



⚠ WARNING

- Store unused batteries out of the reach of children. Contact a doctor immediately if the battery is accidentally swallowed.
- Do not put the remote in a place where it moves when you drive. If it falls under the brake pedal, etc., it will hinder your driving, causing danger.





- Do not set the remote on hot places such as above the dashboard.



- The provided battery is intended for use in operation checking, and their service life may be short.
- When the remote controllable distance becomes short, replace the battery with a new one.

Common features



Power

Press the [POWER] button.




- Unplug the cigarette lighter plug when you turn off the ignition in order to prevent the battery from running out.

Play

Play

Open the cover and insert a disc into the unit.

If a disc has been inserted, press the [▶II] button. Starts playing the disc.



- If you insert a disc, it will start playing from the beginning of the disc.
If you turn the power off while playing a disc, turning the power back on will resume playing the disc where it stopped.

Play of Audio file/Picture file/Video file



- 1 Select the folder**
Press the [◀|/|▶]/[▶|/|▶] button.
- 2 Determine the folder**
Press the [ENTER] button.
The music in the determined folder are displayed.
- 3 Select the file you want to listen to**
Press the [◀|/|▶]/[▶|/|▶] button.
To return to Step 1 to select a folder again, press the [RETURN] button.

4 Play the selected file

Press the [ENTER] button.

Pause

Press the [▶II] button.

Each time the button is pressed, it pauses or plays.

Stop

Press the [■] button.

To restart playback, press the [▶II] button.



- If you press the [■] button twice during DVD playback, it starts from the beginning of the disc next time you play it.

Eject

Press the [EJECT] button.



- If you want to restart playback with the disc ejected from the unit, press the [EJECT] button again. The disc is inserted into the unit, and playback is restarted.
- If you turn off the power or start the engine while playing an audio file, playback may not resume (restart from the point where playback stopped).

Mute

Turning the volume down quickly.

Press the [MUTE] button.

Each time the button is pressed, the Mute turns ON or OFF.

Skip

Skips a chapter, track or file.

Press the [◀◀] or [▶▶] button.



- To skip on a VCD, turn the PBC function off by pressing the [PBC] button.

Fast Forward and Reverse

Press the [◀◀] or [▶▶] button.

The speed changes at 5 levels each time the button is pressed.

To restart playback, press the [▶II] button.

Repeat Play

Plays a song, chapter, title, etc. repeatedly.

Press the [REP] button.

Each time the button is pressed, the Repeat Play function switches as shown below.

In DVD source

Display	Setting
"CHAPTER REPEAT"	Plays the chapter repeatedly.
"TITLE REPEAT"	Plays the title repeatedly.
"REPEAT CANCELED"	Turns Repeat Play off.

In Video file source

Display	Setting
"FILE REPEAT"	Plays the file repeatedly.
"FOLDER REPEAT"	Plays the folder repeatedly.
"ALL REPEAT"	Plays the disc repeatedly.
"REPEAT CANCELED"	Turns Repeat Play off.

In CD/VCD source

Display	Setting
"TRACK REPEAT"	Plays the track repeatedly.
"ALL REPEAT"	Plays the disc repeatedly.
"REPEAT CANCELED"	Turns Repeat Play off.

In Audio file source

Display	Setting
"FILE REPEAT"	Plays the song repeatedly.
"FOLDER REPEAT"	Plays the songs in the folder repeatedly.
"ALL REPEAT"	Plays the disc repeatedly.
"REPEAT CANCELED"	Turns Repeat Play off.

In Picture file source

Display	Setting
"FILE REPEAT"	Plays the picture file repeatedly.
"FOLDER REPEAT"	Plays the folder repeatedly.
"ALL REPEAT"	Plays the disc repeatedly.
"REPEAT CANCELED"	Turns Repeat Play off.



- To repeat play a VCD, turn the PBC function off by pressing the [PBC] button.

Common features

A-B Repeat Play

[DVD] [VCD] [DivX] [CD] [AUDIO]

Specify the Start and End points to play the portion between the specified points repeatedly.

1 Specify Point A (Start point)

Press the [A-B] button.

2 Specify Point B (End point)

Press the [A-B] button.

Plays from Point A to Point B repeatedly.

Canceling A-B Repeat

Press the [A-B] button.

Random Play

[CD] [AUDIO] [DivX] [PIC]

Songs are chosen from those recorded on the disc opened at random and are played.

1 Stop playback

Press the [■] button twice.

2 Select the Random Play mode

Press the [RDM] button twice.

3 For Audio file, select the folder

Select a folder using the [◀]/[▲]/[▶]/[▼] buttons and press the [ENTER] button.

Place the cursor to any file in the folder you want to random play.

4 Start Random Play

Press the [▶II] button.

Canceling Random Play

Press the [■] button twice and [RDM] buttons in order.

Program Play

Plays the selected scene, songs, or files only in order.

1 Stop playback

Press the [■] button twice.

2 Enter the Program mode

Press the [PROG] button.

3 Select the scene, song, or file you want to play

Press the [◀]/[▲]/[▶]/[▼] button.

4 Determine the scene, songs, or file you want to play

Press the [ENTER] button.

When programming for a DVD, select and determine the title and chapter in this order.

5 Repeat Steps 3 and 4 to register all the scenes, songs, or files you want to program play.

6 Start Program Play

Press the [▶II] button.

Canceling Program Play

Press the [■] and [PROG] buttons in order.



- To cancel a programmed song and others, select "CLEAR ALL" and press the [ENTER] button.

Switching Display

Switches the information displayed on the monitor screen.

Press the [DISP] button.

Each time the button is pressed, the display switches as shown below.

In DVD source

Display	Information
"Chapter Elapsed"	Chapter elapsed time
"Chapter Remain"	Chapter remaining time
"Title Elapsed"	Title elapsed time
"Title Remain"	Title remaining time
"Display Off"	Not displayed

In DivX source


Display	Information
"File Elapsed"	Video elapsed time
"File Remain"	Video remaining time
"Display Off"	Not displayed

In VCD (with PBC on) /Audio file source

Display	Information
"Track Elapsed"	Track/file elapsed time
"Track Remain"	Track/file remaining time
"Display Off"	Not displayed

In VCD (with PBC off) /CD source

Display	Information
"Track Elapsed"	Track elapsed time
"Track Remain"	Track remaining time
"Disc Elapsed"	Disc elapsed time
"Disc Remain"	Disc remaining time
"Display Off"	Not displayed



Search Play [DVD] [VCD] [DivX]

Directly calls the scene you want to play.

- 1 Enter the Search mode**
Press the [SRCH] button.



- To search play a VCD, turn the PBC function off by pressing the [PBC] button.

- 2 For DVD, select the Search mode**
Press the [SRCH] button.

Each time the button is pressed, the item that can be called switches as shown below.

Item
Chapter number
Title number



- If you press the [◀] or [▶] button during the Chapter Number Search mode, you can search for a title number.

- 3 Enter the scene you want to play**
Press the [0] – [9] button.

Starts playing the scene you entered during VCD playback.

- 4 For DVD, start scene Search Play**
Press the [ENTER] button.
Starts playing the scene you entered.
- 5 For DVD, enter the time you want to play**
Press the [0] – [9] button.
Starts playing the time you entered.
- 6 For DVD, start time Search Play**
Press the [ENTER] button.
Starts playing the time you entered.
- Canceling Search Play**
Press the [SRCH] button.

DVD menu/Top (title) menu [DVD]

Calls the DVD menu and the Top (title) menu to set up various settings.

1 Display the DVD menu

Press the [MENU] button.

Display the Top (title) menu

Press the [TOP MENU] button.

2 Select the item

Press the [◀]/[▲]/[▶]/[▼] or [0] – [9] button.

3 Finalize the item

Press the [▶II] button.

Refer to the disc manual for instructions on using each menu.

4 Cancel the menu display

Press the [MENU] or [TOP MENU] button.

Audio Language select [DVD]

Press the [AUDIO] button.

Switches the languages recorded on the disc in order.



- If no more than one language is recorded on the disc, it does not switch.

Subtitle Language select [DVD]

Press the [SUB TITLE] button.

Switches the languages recorded on the disc in order.



- If no more than one language is recorded on the disc, it does not switch.

Picture Angle select [DVD]

Press the [ANGLE] button.

Switches the angles recorded on the disc in order.



- If no more than one angle is recorded on the disc, it does not switch.

Zoom

Zooms the image.

1 Select the zoom ratio

Press the [ZOOM] button.

Each time the button is pressed, the zoom ratio changes as follows:

DVD/VCD: x1.0, x2.0, x3.0

Video file: x1.0, x1.5, x2.0, JUST

Picture file: 50, 100, 150, 200 %

2 Select the displaying position (during playback of moving picture only)

Press the [◀]/[▲]/[▶]/[▼] button.

PBC [VCD]

Uses the playback control (PBC) function.

1 Turn the PBC function on

Press the [PBC] button.

Each time the button is pressed, the PBC function turns ON or OFF.

2 Select the item

Press the [0] – [9] button.

3 Finalize the item

Press the [▶II] button.

Refer to the disc manual for instructions on using PBC.



- You can use the PBC function when playing a VCD of Ver2.0 or higher.

Slow Motion play
[DVD] [VCD] [DivX]

1 Pause playback
Press the [▶II] button.

2 Slow Motion play
Press the [◀◀] or [▶▶] button.
Each time the button is pressed, it plays in slow motion as shown below.

Disc	Button	Movement
DVD	◀◀	The speed of slow reverse changes in order of 5 steps.
DVD	▶▶	The speed of slow forward changes in order of 5 steps.
VCD/ DivX	▶▶	The speed of slow forward changes in order of 5 steps.



- To return to the normal speed, press the [▶II] button.

Frame-by-frame playback
[DVD] [VCD] [DivX]

1 Pause playback
Press the [▶II] button.

2 Frame-by-frame playback
Press the [◀] or [▶] button.



- During playback of a video file, frames cannot be advanced in the reverse direction ([◀]).

Slide show [PIC]

Displays the slide show of pictures.

1 Select the folder to view a slide show
Press the [◀]/[▲]/[▶]/[▼]/[ENTER] button.

2 Start the slide show
Press the [▶II] button.



- To specify the display time of a file, select "OTHER" / "JPEG TIME" from <Setup menu> (page 18).


Picture Rotation [PIC]

Rotates the displayed picture.

1 Display the picture you want to rotate
Press the [◀]/[▲]/[▶]/[▼]/[ENTER] button.

2 Rotate the picture

Button	Display
◀	Rotate the picture 90° counterclockwise.
▲	Rotate the picture 180°.
▶	Rotate the picture 90° clockwise.
▼	Rotate the picture 180°.



Direct Skip Play [CD]

Directly calls the song you want to play.

1 Enter the song number you want to play

Press the [0] – [9] button.

2 Play

Press the [ENTER] button.



- If you do not perform the operation of Step 2 for about 5 seconds, the song entered in Step 1 is automatically searched for.

Play Time Search [CD]

Enter the play time to start from where you want.

1 Enter the Play Time Search mode

Press the [SRCH] button.

2 Enter the play time where you want to start

Press the [0] – [9] button.

For example

5:07 → [0], [5], [0], [7]

Starts playing from the time you entered.

3 Play

Press the [ENTER] button.

Search Play [AUDIO]

Directly calls the song you want to play.

1 Select the folder

Press the [◀]/[▲]/[▶]/[▼] button.

2 Determine the folder

Press the [ENTER] button.

The music in the determined folder are displayed.

3 Enter the Search Play mode


Press the [SRCH] button.

4 Enter the song number you want to play

Press the [0] – [9] button.

5 Play

Press the [ENTER] button.



Setup menu

You can customize default settings for various functions of the unit using the Setup menu.

1 Stop playback

Press the [■] button.

During DVD playback, press the button twice.
During VCD playback, turn the PBC function off by pressing the [PBC] button first.

2 Display the SETUP MENU screen

Press the [SETUP] button.

SETUP MENU MAIN is displayed on the monitor screen connected.

3 Select the menu page you want to set up

Press the [▲]/[▼] button.

4 Enter the selected menu page

Press the [ENTER] button.

The menu page selected in Step 3 is displayed.

5 Select the setup item and option

Press the [◀]/[▲]/[▶]/[▼] button.

Refer to the subsequent descriptions for the setup items and options on each menu.

6 Finalize your selection

Press the [ENTER] button.

To return to Step 2 to display the SETUP MENU MAIN screen, press [RETURN].

7 Exit the Setup menu

Press the [SETUP] button.

- To exit the Setup menu, press [SETUP]. If you exit the Setup menu by turning off the power, the settings are not saved.

DISC menu

AUDIO

Set the audio language produced from the speakers.

Display	Setting
"JAPANESE"	Japanese
"ENGLISH"	English
"CHINESE"	Chinese
"ORIGINAL"	Original language

SUBTITLE

Set the language of the subtitles displayed on the screen.

Display	Setting
"AUTO"	Original language
"JAPANESE"	Japanese
"ENGLISH"	English
"CHINESE"	Chinese

MENUS

Set the language of the disc menu.

Display	Setting
"AUTO"	Original language
"ENGLISH"	English
"CHINESE"	Chinese

RATINGS

Set the parental level. The higher the level is, the higher protection you get.

Display	Setting
"0 LOCK ALL"	
"1 KID SAF"	G-rated movies (for children) can only be played.
"2 G"	
"3 PG"	
"4 PG 13"	
"5 PGR"	
"6 R"	
"7 NC17"	
"8 ADULT"	

- 1 Press the [ENTER] button on the remote.
- 2 Set up the parental level.
- 3 Enter the password.
- 4 Press the [ENTER] button on the remote.



- The password is set to "0000" by default.
- The parental setting is enabled for "R" sign discs only.

PASSWORD

CHANGE: Change the password.

- 1 Select "SETTING" and press the [ENTER] button on the remote.
- 2 Enter the current password.
- 3 Enter the new password twice.
- 4 Press the [ENTER] button on the remote.



- The password is set to "0000" by default.

VIDEO menu

TV ASPECT

Use the procedure described below to set the output screen.

Display	Setting
"16:9"	Set the picture mode of the wide-screen monitor to "16:9".
"4:3 PS"	Wide-screen software with pan & scan specification is played in a panned & scanned screen (with the left and right sides cut off).
"4:3 LB"	Wide-screen software with pan & scan specification is played in a letter box screen (with black stripes on the top and bottom).

TV SYSTEM

Select the video output signal suitable for the TV monitor you use.

Display	Setting
"NTSC"	Outputs the video signal using the NTSC system.
"PAL"	Outputs the video signal using the PAL system.
"AUTO"	Switches between the NTSC and PAL systems automatically according to the type of the video signal of the disc you play.



- Turning off the power restores the default setting ("PAL").

STILL MODE

Set the still (pause) image display mode.

Display	Setting
"AUTO"	Detects the image motion speed automatically to perform the optimum image processing.
"FIELD"	Performs the optimum image processing when the image motion is fast.
"FRAME"	Performs the optimum image processing when the image motion is slow.

Setup menu

AUDIO menu

LPCM DOWNSMPL

Display	Setting
"OFF"	Does not perform down-sampling.
"48kHz"	Outputs a song of 96kfs in 48kfs from DIGITAL OUT.
"96kHz"	Outputs a song of 96kfs in 96kfs from DIGITAL OUT.

DOLBY DIGITAL

Sets the Dolby digital sound output form.

Display	Setting
"BITSTREAM"	Outputs sound in Bits stream form.
"PCM"	Outputs sound in PCM form.
"OFF"	Does not output sound.

DTS

Sets the DTS sound output form.

Display	Setting
"BITSTREAM"	Outputs sound in Bits stream form.
"PCM"	Outputs sound in PCM form.
"OFF"	Does not output sound.

MPEG

Sets the MPEG sound output form.

Display	Setting
"BITSTREAM"	Outputs sound in Bits stream form.
"PCM"	Outputs sound in PCM form.
"OFF"	Does not output sound.

DYNAMIC RANGE

Narrows the dynamic range to allow you to listen to movie dialogues clearly.

Display	Setting
"ON"	Narrows the dynamic range.
"OFF"	Does not adjust the dynamic range.

DISPLAY

LANGUAGE

Sets the language of the setup menu.

Display	Setting
"中文"	Chinese
"ENGLISH"	English
"FRANÇAIS"	French
"ESPAÑOL"	Spanish
"DEUTSCH"	German
"ITALIANO"	Italian

OTHER

JPEG TIME

Sets the picture display time.

Display	Setting
"1 SEC"	Displays the picture for 1 second.
⋮	
"180 SEC"	Displays the picture for 180 seconds.

Press the [▲] or [▼] button to select the second.

DEFAULTS

RESET: Resets the customized items on the Setup menu.









REGISTRATION

SHOW CODE: Displays the DivX registration code.



- When downloading a DivX VOD file controlled by DRM, register the code appeared on the screen. Otherwise the file may not be able to play with this unit.
Remaining number of viewing is displayed when playing a DivX VOD file with the viewing restriction. When the remaining number of viewing reached 0, a warning message appears and the file cannot be played.

Accessories


①	1
②	1
③	2
④	5
⑤	4
⑥	2
⑦	1
⑧	1




- If the fuse blows, first make sure that the wires have not caused a short circuit, then replace the old fuse with one with the same rating.

Installation


Installation using the brackets




Installation using the Velcro tapes



- Do not use your own screws. Use only the screws provided. If you use the wrong screws, you could damage the unit.
- Do not install the unit to an unstable place and a place where it vibrates.
- You can mount the unit at any angle between the regular horizontal position and the vertical position on its back (0° through 90°). You cannot mount the unit with the disc slot facing downwards, angled or upside down.



Connecting Wires to Terminals





Attaching Remote Control Sensor

- 1 Remove the backing paper from the Velcro tape on the back of the Remote Control Sensor.
- 2 After wiping off the dirt or oil from the attachment location, attach the Remote Control Sensor.



- Wipe off the dirt or oil from the surface to which the Sensor is attached.
- Avoid locations under direct sunlight or near the TV monitor where signals from the remote controller are not received easily.
- You can change the direction of the remote control sensor cable.



- Connect the power cable ① to the DVD player first, and connect it to the cigarette lighter socket last. Connecting it to the cigarette lighter socket first may blow the fuse.

Troubleshooting Guide

What might seem to be a malfunction in your unit may just be the result of slight misoperation or miswiring. Before calling service, first check the following table for possible problems.

? The sound/picture skips on a DVD/VCD/CD.

- ✓ The disc is scratched or dirty.
 - 🔧 Clean the disc, referring to the section on <Handling discs> (see page 5).

? A VCD cannot be played using menus.

- ✓ The VCD disc being played is not compatible with P.B.C.
 - 🔧 Menu playback is available only with VCD discs recorded with P.B.C.

? The subtitle is not displayed.

- ✓ The DVD disc being played does not contain the recording of subtitles.
 - 🔧 The subtitle cannot be displayed when the DVD disc being played does not contain the recording of subtitles.

? The voice (or subtitle) language cannot be changed.

- ✓ The DVD disc being played does not contain the recording of more than one audio (or subtitle) language.
 - 🔧 The voice (or subtitle) language cannot be changed when the DVD disc being played does not contain the recording of more than one voice (or subtitle) language.

The messages shown below display your systems condition.

"Thermal Protect. Off Power!"

- : The protective circuit in the unit activates when the temperature inside the DVD player exceeds 60°C (140°F), stopping all operation.
 - ↔ Cool down the unit by opening the windows or turning on the air conditioner. As the temperature falls below 60°C (140°F), the disc will start playing again.
- To eject the disc in this situation, turn the power off and then turn it back on.

"NO DISC"

- : No disc is inserted in the unit.

"THIS DISC MAY NOT BE PLAYED IN YOUR REGION"

- : A DVD with the wrong region code was inserted into the unit.

"Unknown DISC"

- : A disc that cannot be played in the unit was inserted.
- : The disc inserted contains damaged or non-standard data.

"PASSWORD IS DIFFERENT!"

- : The password entered does not match the one registered.
- : Appears if the second new password entered does not match the first one when changing the password.
 - ↔ When you enter the new password, you are required to enter the same password twice for confirmation.

Specifications

Specifications subject to change without notice.

DVD section

- D/A Converter
 - : 8Level $\Delta\Sigma$, 24bit
- Wow & Flutter
 - : Below Measurable Limit
- Frequency response
 - : 17- 44 kHz (DVD 96kHz Sampling)
- Total harmonic distortion 1kHz
 - : 0.02 %
- Signal to noise ratio
 - : 110 dB (DVD Video 96k)
- Dynamic range
 - : 90 dB
- Decode Format
 - : Linear PCM, Dolby Digital, dts, MP3, WMA, AAC
- DISC Format
 - : DVD-VIDEO/ VIDEO-CD/ CD-DA

Output

- Composite Video Output Level (V)
 - : 1 Vp-p (75 Ω)
- Audio 2ch Output Level (V)
 - :1.2 V/ 10 k Ω (DVD/CD)
- Coaxial Digital Audio Interface Output Level (V)
 - : 0.5 V/ 75 Ω

General

- Operating voltage
 - : 14.4 V (11 – 16 V)
- Current consumption
 - : 2 A
- Dimensions WxHxD
 - : 195 mm x 45 mm x 210 mm
- Weight
 - : 1.7 kg

DivX, DivX Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

DVD is a trademark of DVD Format/Logo Licensing Corporation registered in the U.S., Japan and other countries.

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

"DTS" is a registered trademark of DTS, Inc. and "DTS 2.0 + Digital Out" is a trademark of DTS, Inc.

The "AAC" logo is trademark of Dolby Laboratories.

This Product is not installed by the manufacturer of a vehicle on the production line, nor by the professional importer of a vehicle into an EU Member State.

Information on Disposal of Old Electrical and Electronic Equipment (applicable for EU countries that have adopted separate waste collection systems)



Products with the symbol (crossed-out wheeled bin) cannot be disposed as household waste. Old electrical and electronic equipment should be recycled at a facility capable of handling these items and their waste byproducts. Contact your local authority for details in locating a recycle facility nearest to you. Proper recycling and waste disposal will help conserve resources whilst preventing detrimental effects on our health and the environment.

The marking of products using lasers (Except for some areas)



The label is attached to the chassis/case and says that the component uses laser beams that have been classified as Class 1. It means that the unit is utilizing laser beams that are of a weaker class. There is no danger of hazardous radiation outside the unit.