KENWOOD

Speed Camera POI's

NB: These instructions suggest the use of third party software and database. Kenwood Electronics UK Ltd do not support, or accept liability for this software.

This database is provided by Pocket GPS World which requires a yearly subscription fee and updates are available approximately every month. To download the database and upload onto your Kenwood Navigation System you will require a USB stick (File size is approximately 1MB).

⚠️ *In some countries the use of speed camera's are prohibited please check the legality of using any speed camera POI's in each country beforehand.*

How to Upload Speed Camera POI's

1. The first step is to download, and install, the free POI Loader software from Garmin's web-site: http://www8.garmin.com/products/poiloader/

2. Once installed the next stage is to register and subscribe to pocketgpsworld.com: http://www.pocketgpsworld.com/subscription.php

3. Create a folder on your computer and give it a name such as **'Speed Camera Database'**

4. Download database: http://www.pocketgpsworld.com/modules.php?name=Cameras

When you get this screen:

5. Select **'Garmin POI Loader'** from the list and then press **'Continue'**

6. Then select **'UK – Consolidated by type (Gatso, Mobile etc)'**

7. Choose to save the file to your desktop or **'My Documents'**.

8. The downloaded file is a zipped up file. Right click on it and unzip/extract it to the folder that you created earlier – ie **'Speed Camera Database'** folder.

Transfer to USB Stick:

9. Plug a blank USB stick into your computer and start the POI Loader software.

10. Select **"Garmin Device"** on this page:

11. Next you will be asked to select the location of your USB device, for example **"Removable Disc (H:\)"**

12. On the next screen, select **"Install new custom POIs onto your device"**

13. The next page will ask you where you have stored the data files.

Click "Browse" and select the new folder that you created earlier called **"speed camera database"** and change the other settings as below

<---- Set to **poi**

<---- Set to **Feet and MPH**

<---- Set to **Express (Recommended)**

14. Then click **"Next"** and the POI Loader software will create the necessary folders and files on your USB device.

15. Confirm that your USB device has the following folders and file: **Garmin/POI/poi.gpi**

Upload to Kenwood Navigation System:

16. Power up Kenwood navigation System

17. Select **[NAVI]**

18. Go to the **"WhereTo/View Map"** screen

19. Connect the USB stick to the USB input and follow the on-screen instructions to upload the safety camera database.

20. When complete you can remove the USB device.

Please ensure that you do not interrupt the upload or turn off engine until completely finished.