# **PS-60**

## INSTRUCTION MANUAL

**KENWOOD** 

**Kenwood Corporation** 

© B62-2332-00 (T)

We are grateful you purchased this Kenwood DC Power Supply.

#### SUPPLIED ACCESSORIES


AC Power Cable (2 m/ 6.5 feet)1
Instruction Manual1
Warranty Card1

#### **PRECAUTIONS**

- Do not expose the unit to rain or moisture to avoid the risk of fire or electric shock.
- Do not touch the power plug when your hands are wet to avoid risk of electric shock.
- Do not remove the case. Accidentally touching an internal part may result in serious electric shock.
- If a metal object such as a hair pin or a needle comes into contact with the power socket on the rear panel, a dangerous electric shock may occur.
- Keep children away from the unit, to avoid unnecessary risk of harm to the child.
- Always remove the plug from an AC outlet by pulling on the plug, not the cable.
- Position the AC cable so it will not be stepped on, tripped over, nor subjected to damage.
- Plug the AC cable only into a grounded AC outlet.
- Unravel the AC power cord before use.
- In case of an abnormality in the equipment, ensure the equipment is plugged into an outlet that can be easily accessed, so that the plug may be disconnected from the outlet.
- To avoid equipment damage, do not connect to a transceiver that operates on a voltage other than 13.8 V DC or exceeds the current rating.
- Do not expose the unit to long periods of direct sunlight, nor place it close to heating appliances.
- Do not place the unit in excessively dusty and/or humid areas, nor on unstable surfaces.
- Do not block the power supply air vent. Do not cover the unit.
  To maintain good ventilation, place the unit at least 10 cm (4 inches) away from the wall.
- Do not use solvents such as benzene or paint thinner to clean the unit. Use a silicone or a clean, dry cloth.
- Do not install this equipment in a constricted location, such as a book case.
- If you detect an abnormal odor or smoke coming from the unit, turn OFF the power immediately and disconnect the power cord. Contact your **Kenwood** service center or dealer.

## **ORIENTATION**


## **Front Panel**



#### Power switch

Press this switch to turn the power ON and OFF.

#### **Rear Panel**



- This power supply is for use with a transceiver. Do not use the power supply with other products.
- Before connecting the DC power cable to the transceiver terminal, or removing it from the terminal, turn the power supply power OFF.
- For connection instructions, refer to the transceiver instruction manual.
- When placing the power supply beside the transceiver, adjust the power supply bail to an appropriate angle. You can further use commercially available rubber pads/ feet to adjust the angle to match that of the transceiver.

0401/40 400/ 50/0011-

#### SPECIFICATIONS

D-----

Power requirements
Output voltage
Rated output current
Operating temperature range10°C $\sim$ + 50°C (-22°F $\sim$ +130°F)
Dimensions (W x H x D) <wi>thout projections&gt; <math display="block">173.5 \times 95.5 \times 204.3 \text{ mm} (6.83 \times 3.76 \times 8.04 \text{ in})</math></wi>
Dimensions (W x H x D) <with projections="">175.9 x <math>108.6</math> x <math>228.1</math> mm <math>(6.93</math> x <math>4.28</math> x <math>8.98</math> in)</with>
Weight approx. 2.5 kg (5.5 lb)
AC Plug 3 pin (Grounded)

Information on Disposal of Old Electrical and Electronic Equipment (applicable for EU countries that have adopted separate waste collection systems)



Products with the symbol (crossed-out wheeled bin) cannot be disposed as household waste.

Old electrical and electronic equipment should be recycled at a facility capable of handling these items and their waste byproducts. Contact your local authority for details in locating a recycle facility nearest to you. Proper recycling and waste disposal will help conserve resources whilst preventing detrimental effects on our health and the environment.



**Authorized Representative in Europe:** 

Kenwood Electronics Europe B.V.

Amsterdamseweg 37, 1422 AC Uithoorn, The Netherlands **Manufacturer:** 

Kenwood Corporation

1-16-2 Hakusan, Midori-ku, Yokohama-shi, Kanagawa, 226-8525 Japan